

APPLICATION EQUIPMENT

Millennium One Step™ Battery Powered Applicator



DESCRIPTION

Millennium One Step™ Battery Powered Applicator is specifically designed to be used with the Millennium One Step™ family of adhesives and sealants. The unique carriage design is extremely durable and allows the user to install adhesive in an upright position eliminating back strain. The tool is powered by a Li-ion 20 volt rechargeable battery. The motor is designed to run on lower amps than conventional cordless tools which extends overall battery life and reduces charging time.

USER INSTRUCTIONS

1. Assemble carriage handle using the provided (4) screws and lock nuts with the wrench and allen key (also included).
2. Open the clutch lever to allow movement of the racks. Retract the rack by pulling the rack handle away from the tool.
3. Prepare adhesive cartridge by removing caps or plugs and installing static mixing nozzle. Note: Follow adhesive manufacturers complete instructions for cartridge preparation.
4. Insert cartridge into the carriage. Line up the cartridge and the cartridge nozzle opening for correct positioning.
5. Push the rack handle forward, lining up pistons with the openings on the cartridge. Close the clutch lever to engage clutch.
6. Slide the battery onto the handle until it is fully engaged.
7. Adjust speed control knob to desired flow. Full speed is designated on the knob by the largest “bubble” symbol. Slower speeds; smaller bubbles. Note: Most applications will require the tool to be operated at full speed.
8. Hold trigger to begin dispensing adhesive. Note: Trigger must be depressed 2 times before tool operates when it has remained idle. This is a power saving feature built into the tool.
9. When finished dispensing, or when end of cartridge is reached, release trigger, open clutch, then retract rack. Remove cartridge.

SAFETY

Protective equipment such as safety glasses and protective gloves must be worn when operating or servicing the Millennium One Step™ Battery Powered Applicator.

The Millennium One Step™ Battery Powered Applicator should never be pointed at or near people. The applicator should never be actuated when the outlet tip of the adhesive cartridge is blocked or restricted by cured adhesive, any object, or some part of the body.

Prior to working with this applicator thoroughly review the Instruction Manual provided with the tool.

FEATURES

BENEFITS

Battery powered	Portable, no cords or hoses
Quick and easy use	Saves time and labor
Trigger delay	Saves battery charge
Durable construction	Withstands everyday use
Strong motor	Can dispense higher viscosity adhesives



MAINTENANCE INSTRUCTIONS

- Keep handles clean, dry and free of oil or grease.
- Clean with mild soap and damp cloth. Do not use solvents or cleaning agents that can damage the tools plastic parts.
- Follow cleaning and maintenance instructions in battery charger manual and battery pack leaflet.
- Remove adhesive residue from rack and pistons regularly if present. Apply light coating of light machine oil to lubricate rack as needed.
- For internal lubrication and all other maintenance, except external cleaning and battery pack recharging, and for all repairs, return to service center, distributor, or manufacturer.
- If the tool is not running at full capacity, check to be sure that the battery pack is fully charged and that the contacts on the battery pack and tool are both clean. If they need maintenance, use caution and clean with an eraser.

SERVICE

Tool service must be performed only by qualified repair personnel. Service or maintenance performed by unqualified personnel may result in risk of an injury. Do not disassemble tool or battery pack. At the conclusion of it's useful life, remove battery pack from tool. Without further disassembly, return battery pack intact for recycling and/or discard tool intact. Information on battery pack recycling can be found in the Instruction Manual provided with the tool. Disassembly and reassembly may create an unsafe condition.

When servicing a tool, use only identical replacement parts. Use of unauthorized parts or failure to follow maintenance instructions may create a risk of electrical shock or injury.

PACKAGING

Millennium One Step™ Battery Applicator:

North America

DESCRIPTION	PART #
Complete Applicator with 20 V Li-ion Battery NA	EQ-7075-KIT-LINA
20 V Li-ion Charger with NA Cord Set	EQ-7075-CGR-LINA
Cord Set NA Charger	EQ-7075-CORD-NA
Replacement 20 V Li-ion Battery	EQ-7075-BAT-LI

Europe, CIS, and Middle East

DESCRIPTION	PART #
Complete Applicator with 20 V Li-ion Battery EU	EQ-7075-KIT-LIEU
20 V Li-ion Charger with EU Cord Set	EQ-7075-CGR-LIEU
Cord Set EU Charger	EQ-7075-CORD-EU
Replacement 20 V Li-ion Battery	EQ-7075-BAT-LI

ADDITIONAL ACCESSORY

ADDITIONAL ACCESSORY	PART #
Applicator Carrying Case (Special Order)	EQ-7075-CASE

The One Step™ Battery Powered Applicator includes 2 rechargeable Li-ion batteries, 1 battery charger, and 1 detachable carriage handle.

*Refer to the Millennium One Step™ Battery Powered Applicator Instruction Manual for complete use and safety information.



For more information about our company, visit www.hbfuller.com/roofing.

 Join the Conversation | www.hbfuller.com/connect

WARRANTY: H.B. Fuller warrants its products to conform to H.B. Fuller's specifications at the time of sale when tested according to H.B. Fuller standards. If a product is proven to be defective when tested according to H.B. Fuller standards, H.B. Fuller will, at its option, refund the purchase price or replace or repair the defective product. THIS LIMITED WARRANTY IS THE BUYER'S SOLE AND EXCLUSIVE REMEDY AGAINST H.B. FULLER AND IS IN LIEU OF ANY AND ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. In no event shall H.B. Fuller be liable for any special, incidental, consequential, or punitive damages arising out of any claims whether based on negligence, contract, warranty, strict liability or otherwise.